# Go!Control

HOW TO REPLACE BATTERIES

At times you may need to periodically replace the batteries in your wireless security sensors and Z-Wave devices, such as your door lock.

 The easiest way to replace batteries for wireless devices is to put the Go!Control panel in a system test.







2. Once the panel is in a system test, you can open the individual sensor and replace the batteries.



- 3. Z-Wave device batteries can be replaced at any time without being in a system test.
  - For the Thermostat, take the bottom cover off and replace the batteries.
  - For the Door Lock, open the cover of the interior case and replace the batteries.



