IQ FALL PENDANT QUICK INSTALL GUIDE



CONVENIENCE ON A LANYARD

The IQ Fall Pendant is designed for a user to push the button for help at any time. It can also automatically^{*} activate an emergency alarm if it detects a fall in the event that the user is unable to trigger an alarm by pressing the button.



* Note: fall sensors do not detect 100% of falls. If you are able to do so, you should always press the button if you need help. Do not activate the fall sensor twice within a 10-second interval.

SPECIFICATIONS

Housing Dimensions: 2.32"H x 1.67"W x .75"D Oval

Button Function: Press=Activate, Release=Restore Supervisory Signals: sent every hour. Transmitter frequency: 319.5 MHz Water Resistant: Rated IP45, protected from low pressure water jets in any direction.

Battery: 3V CR2477 (x1). Typical battery life of 2 years with an average of one activation per day.

LED BATTERY INDICATORS:

LED Off	Standby Mode
3 Red Flashes	Powering On
1 Green Flash	Transmitting with good Battery
1 Red Flash	Transmitting with Low Battery

This is a quick guide for experienced installers only. Refer to http://dealers.qolsys.com (login required)



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme avec Industrie Canada exempts de licence standard RSS (s). Son fonctionnement est soumis aux deux conditions suivantes: (1) cet appareil ne doit pas provoquer d'interférences et (2) cet appareil doit accepter toute interférence, y compris celles pouvant causer un mauvais fonctionnement de l'appareil.